



## SSS Fast Coat System

### SSS Fast Link Bonding Agent (Step 3)

SSS Fast Link is a revolutionary way to prepare sports and commercial wood floors for recoating. All dust, mess and equipment associated with screening is eliminated when using Fast Link. Applied in a liquid state, Fast Link chemically prepares the floor and ensures finish adhesion. SSS Fast Link is Step 3 in the Fast Coat System, which has significant labor and time savings for recoating wood floors.

#### TYPICAL PROPERTIES

Color..... Translucent (dries clear)  
Drying Time..... One hour (with good ventilation and air movement)  
VOC ..... Does not exceed 115 gallons/liter excluding water 0.96 lbs./gal.  
Flash Point ..... Greater than 200°F  
Clean Up ..... Water  
Freeze/Thaw Stability ..... Stable (if frozen, thaw completely before using)  
Storage..... Do not store above 120°F (49 degrees C)

#### COVERAGE

Approximately 2,500 square feet per gallon, depending on conditions.

#### RECOMMENDED APPLICATION

One thin coat of SSS Fast Link followed after 1 hour and before 6 hours with a single coat of SSS Commercial Topcoat or two coats of SSS Multi Use Topcoat or Sports Floor Topcoat.

#### PACKAGING

Gallons, 4 per carton.

#### APPLICATION PROCEDURE

**NOTE** – Fast Link is recommended for recoat applications only. Do not use over any waxed surfaces. If unsure, always prepare a test patch to determine potential adhesion.

1. Step 1 is to clean the floor with SSS Power Cleaner Concentrate according to the label directions. Be sure floor is entirely free of dirt, oil and other residue. Rinse the floor by damp mopping with clean water. Step 2 is to clean the floor again with SSS Maintenance Cleaner according to label instructions. The two cleaners are specifically formulated to remove different types of contaminants and must not be combined into a single treatment. Allow the floor to dry completely
2. Step 3 is to apply a thin film of SSS Fast Link over the dry floor with a clean rayon string mop as directed on the label instructions. Cover the complete floor.
3. Allow Fast Link to dry approximately one hour with good ventilation and air movement across the floor. Do not exceed six hours before applying the selected topcoat or SSS Fast Link may lose effectiveness. If the six-hour window is surpassed, application of another coat of SSS Fast Link will be necessary.
4. Apply the SSS Fast Coat topcoat of your choice according to label instructions.

#### OBLIGATION OF MANUFACTURER/SELLER

The following is made in lieu of all warranties, expressed or implied. Seller's and manufacturers only obligation shall be to replace such quantity of the product proved to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct, or incidental or consequential,

arising out of the use of or the inability to use the product. Before using, the user shall determine the suitability of the product for his intended use and user assumes all risk and liability whatsoever in connection therewith. The foregoing may not be altered except by an agreement signed by officers of seller and manufacturer.